

Information Handbook

Vehicle Details

Make/Model: Rollerteam Autoroller 746

REG PO25 DDA

Height: 3.2m

Length: 7.24m (plus bikes)

Width: 2.35m (mirrors folded)

M.T.P.L.M 3500kg

Fuel Diesel

Gas Propane

(safefill bottle – user refillable at most LPG pumps on forecourts)

www.safefill.co.uk

If you need to contact us during your hire



WHATSAPP US!

+44 (0)7980 382599

(usually the fastest way to get a reply)

Please only after 5pm if it is an emergency

Email us – info@southlakesmotorhomehire.com

or call us on

01229 440113

9am to 5pm

(leave us a message if we don't pick up first time)

External Features



Electric

The hook up lead is stored in the gas locker. It is used to connect the vehicle to the mains power supply on a campsite. The vehicle hook-up point is located on the passenger side. Lift the cover, plug the cable into the vehicle and then connect the other end of the cable into the electricity bollard on site.

Once you are hooked up and on 240v power supply the 3-pin power outlets in the vehicle will work.



Main Control Panel

This panel controls heating, hot water, lights & water pump.

Hot water – takes approx. ½ hour to reach temperature



Full operating instructions can be found on our You Tube video

[https://youtu.be/tgpbQUTXqSM?si= 0Er5UUyp0wAISpH](https://youtu.be/tgpbQUTXqSM?si=0Er5UUyp0wAISpH)

TV

The TV/DVD player is 12v and so can be used pretty much all the time whether you have a mains electricity supply or not.

There is a USB connection to the rear where you can plug in a memory stick or external hard drive with movies etc. to watch. You can also use the PVR capabilities if using a USB.

The TV uses WiFi connection to stream live TV via apps such as ITV player etc.

There is no terrestrial aerial connection. If there is no mobile reception internet based TV will not function. If TV is important to you we recommend you bring some DVD's

WiFi

The WiFi box is located in the cupboard above the TV

Unlimited data is provided. Availability & speed of connection depends on local signal and cannot be guaranteed

GAS

The gas cylinder is located on the passenger side of the vehicle in the gas locker.

You will find a full “Safefill” gas cylinder fitted to the vehicle.

We recommend that you keep the bottle topped up so you don’t run out just as you need it!

You can obtain refills at petrol stations that dispense Auto-gas. Safefill are partnered with Morrisons supermarket and also provide a handy map of other independent petrol stations that will be happy to refill you. There are hundreds dotted all around the country.

<http://www.safefill.co.uk/refilling-retailers.html>

There is a no need to bring the bottle back full – we will swap it out for a full bottle on your return.

To switch on the gas – make sure that the connection into the bottle is properly tightened – it may have come loose during transit. Once you are satisfied that the bottle is correctly connected open the valve on the top of the bottle. There are markings on the value to indicate which way to open and close.

On the rear wall of the compartment you will see a silver regulator. There is a yellow valve below it. This is the inline valve to cut off supply into the motorhome. It must be vertical (in line with the pipe) to be open and allow gas into the motorhome.



Handwheel to connect cylinder and hose –
no tools are required.

Yellow valve after regulator to shut off
supply into motorhome

Gas locker contents - One user-refillable SafeFill cylinder & One full Calor Bottle.

The calor bottles is for emergencies where you have run out of gas and cannot find a retailer to refill the gas bottle. Please do not use it unless you absolutely have to as they are expensive to replace compared to refilling the safefill bottle.

Also in locker – Electric hook up cable, adapter – mains plug to motorhome plug & towing eye

It is good practice to switch off at the cylinder at night an when moving.

IT IS ILLEGAL TO USE GAS APPLIANCES WHILST MOVING

WATER

Water filling point is located on the driver side

Lift flap and remove blue cap.

TAKE CARE NOT TO LOSE THE BLUE CAP

A hose for filling the fresh water can be found in the garage

Please do not misplace the connection pieces as they may be needed depending on the tap arrangement at each campsite.

There is usually a specific tap identified for the purposes of fresh water. It is usually separate from the taps used for grey water flushing and WC emptying point as these may be contaminated.

Please ensure you use the correct tap.

The hose is not to be used for the purposes of swilling out of toilets, grey waste or washing down the vehicle. Please keep it off the ground so that it remains clean for the use of others.

Although we regularly sanitise the water tank we cannot guarantee the quality or cleanliness of water sources used by previous customers to fill the onboard water tank. With that in mind we strongly recommend that any water is boiled before drinking or used for cooking.

Bottles of drinking water can be purchased cheaply from local supermarkets and we would recommend you use these for your drinking water.

Dining Table

Front Dinette – Can be left up when driving as it is attached to the wall.

Rear Lounge – the table is in the tall locker next to the sink. It must be stowed when travelling.

DO NOT use this table outside. It is only suitable for use inside the motorhome.

Toilet

Before using the toilet ensure that the blade (that prevents things going down the toilet) is open. Push the grey handle on the side of the toilet across to open the blade. When finished flush the toilet by pressing the button behind the toilet (this will only work when the water tank has water in it and the pump is switched on). Once flushed close the blade to prevent waste splashing back up out of the tank.

The toilet cassette is accessed from the small door on the driver's side of the vehicle. Before doing anything please go inside the vehicle and check that the blade is closed. Remove the cassette and take it to the campsite chemical toilet disposal point. If you feel any resistance double check that the blade is closed. Forcing the cassette out will damage the mechanism and is costly to replace.

When you return to the vehicle put a single sachet of toilet chemicals back into the tank.

NOTE the chemical toilet must be clean and empty on the return of the vehicle or there will be a charge applied as per the T&Cs of hire. You can only empty at designated chemical toilet emptying points and you must not dispose of it anywhere else. The chemicals provided are septic tank safe.

Grey waste

The vehicle is fitted with a grey waste holding tank (shower water, sink water). The electronic display above the habitation door will give you an indication of the levels within the tank. To empty the tank there is a tap outside of the vehicle on the driver side, just under the fresh water fill point. Drive over a grating on site and then turn the tap which will allow the waste out. Most sites provide a drive over "Motorhome waste disposal point" for this purpose. If they do not you must find a suitable disposal point before emptying.

Do not empty down undesignated drains or onto pitches, parking or road surfaces.

Beds

The overcab bed is on gas struts and you simply need to pull down to access it.

When you are putting the bed away push it back up and secure with the clip. You'll find the ladder for the bed up on the mattress. There is a safety net tucked under the mattress. Due to the height this bed is not recommended for children under the age of 6 and they must be supervised by a responsible adult at all times.

The rear lounge is a flexible space and can be made into a large bed. The infill pieces are located on the overcab bed. Please see video on our youtube channel for how to make the bed.

The central dinette makes into a small double just place the table down in the gap between the two seats and use the infill piece stored on the overcab bed to fill in the gap.

On the fixed overcab bed we've provided a waterproof mattress protector. Please use them, any damage or stains to mattresses will be charged. You will need to bring your own bedding and towels

For your guidance the bed sizes are given below and in brackets recommended bed sheet sizes

Overcab Bed	209 x 160 cm (superking)
Front Dinette	186 x 126 cm (small double)
Rear Lounge	216 x 169 cm (superking)

Fridge



To switch on:

Push the on/off switch and hold until the buttons will light up blue.

Selecting power source:

Press and hold the square button until the lights in the first section (the power sources) flash. press the > or < buttons to highlight your chosen power source. Press the Square button again to select

Next you will select the Cooling Level:

press the > or < buttons to highlight your chosen cooling level. Press the Square button again to select

Whilst driving ensure that all items in the fridge have been securely stored.

The fridge will remain cold for several hours when the door remains closed. If you are wild-camping or on sites without mains power then we recommend running on 12v during your journey to get the temperature of the fridge down and then using the gas to give it a boost if you feel it is warming up.

Keep the door closed as much as possible.

Available power sources:

Plug Symbol – 240V Mains power (when connected on a campsite)

Battery Symbol – 12v leisure battery (only when engine running)

Flame Symbol – Gas – automatic ignition. If it fails to ignite then restart the fridge and select the gas source again. For safety reasons, it is not possible to ignite the gas within 15 minutes after driving.

A symbol – automated. The fridge will chose its own power source based on what is available

Oven/Hob

The oven is controlled using the dial on the right hand side. Turn left and select the appropriate temperature. Whilst pushing the button in press the ignition button and the gas will light. You will see a row of flames at the rear of the oven.

Turn the dial to the right to operate the grill.
Push the button in whilst pressing the ignition button to light. You will see the flames in the grill at the top of the oven. The door must be open for the grill to work.

To use the hobs, turn the appropriate dial to the flame symbol and push in to ignite

Please ensure the oven, hobs and all associated racks and grids are cleaned prior to the return of the vehicle.

Checklist before driving off

- Gas bottles secured and valves closed
 - Electric lead disconnected and stowed away
 - Glass cooker lid must be down
 - All openings must be closed
- (Doors, windows, ceiling windows/vents, cupboards and drawers)

Double check the overcab bed windows!!

- Toilet Cassette blade closed
- All passengers must travel with seatbelts on
- All loose items secured to prevent movement whilst in transit

At the end of your hire please ensure:

- The toilet cassette is empty and rinsed out
- There are two gas bottles in the gas locker
 - Waste water tank is empty
 - The fuel tank is full (diesel)
- The interior of the vehicle cleaned – please pay particular attention to the toilet, under the shower tray and the oven and fridge. We will charge for cleaning where it is not returned to the same standard of cleanliness as when it was handed over.

Please park the vehicle across the street where it was when you collected it so as not to block our neighbours driveways

If you are going to be late please CALL us.

Late returns have a negative impact on the next guest and we charge for late returns accordingly.